

Gamsco

DIGITAL MULTIMETER

KM-9648 SERIES



DISPLAY		Red high efficiency LED high 14.22mm (.56")
ACCURACY		± 0.5% ± 2 digit
OPERATING CONDITION		-10°C~50°C (20% to 90% RH non-condensed)
DIELECTRIC STRENGTH		AC 2KV/1min
AUX. POWER		AC110V/220V 50/60Hz
MEASUREMENT RANGE	KM9648-KW1	<p>Function: Multi Range KW Meter. Display single phase power.</p> <p>Input Current: For Current below AC 5A, the meter can be used directly. For Current above 5A, Current Transformer (C.T.) must be used. Press Key \curvearrowright to select desirable C. T. Ratio. The following are the available C.T. Ratios: 10A/5A, 15A/5A, 20A/5A, 25A/5A, 30A/5A, 40A/5A, 50A/5A, 60A/5A, 70A/5A, 75A/5A, 80A/5A, 100A/5A, 120A/5A, 150A/5A, 160A/5A, 200A/5A, 250A/5A, 300A/5A, 400A/5A, 500A/5A, 600A/5A, 700A/5A, 750A/5A, 800A/5A, 1kA/5A, 1.2kA/5A, 1.5kA/5A, 1.6kA/5A, 2kA/5A, 2.5kA/5A, 3kA/5A, 4kA/5A, 5kA/5A, 6kA/5A, 7kA/5A, 7.5kA/5A, 8kA/5A.</p> <p>Input Voltage: AC 50-600V.</p>
	KM9648-KW3	<p>Function: Multi Range KW Meter . 3Ø3W</p> <p>Input Current: For Current below AC 5A, the meter can be used directly. For Current above 5A, Current Transformer (C.T.) must be used. Press Key \curvearrowright to select desirable C. T. Ratio. The following are the available C.T. Ratios: 10A/5A, 15A/5A, 20A/5A, 25A/5A, 30A/5A, 40A/5A, 50A/5A, 60A/5A, 70A/5A, 75A/5A, 80A/5A, 100A/5A, 120A/5A, 150A/5A, 160A/5A, 200A/5A, 250A/5A, 300A/5A, 400A/5A, 500A/5A, 600A/5A, 700A/5A, 750A/5A, 800A/5A, 1kA/5A, 1.2kA/5A, 1.5kA/5A, 1.6kA/5A, 2kA/5A, 2.5kA/5A, 3kA/5A, 4kA/5A, 5kA/5A, 6kA/5A, 7kA/5A, 7.5kA/5A, 8kA/5A.</p> <p>Input Voltage: AC 50-600V.</p>
	KM9648-PF1	<p>Function: Power Factor Meter - Single Phase.</p> <p>Range: LEAD 0.5-1-0.5LAG.</p> <p>Input Current: For Current below AC 5A, the meter can be used directly. For Current above 5A, Current Transformer (C.T.) must be used. Press Key \curvearrowright to select desirable C. T. Ratio. The following are the available C.T. Ratios: 10A/5A, 15A/5A, 20A/5A, 25A/5A, 30A/5A, 40A/5A, 50A/5A, 60A/5A, 70A/5A, 75A/5A, 80A/5A, 100A/5A, 120A/5A, 150A/5A, 160A/5A, 200A/5A, 250A/5A, 300A/5A, 400A/5A, 500A/5A, 600A/5A, 700A/5A, 750A/5A, 800A/5A, 1kA/5A, 1.2kA/5A, 1.5kA/5A, 1.6kA/5A, 2kA/5A, 2.5kA/5A, 3kA/5A, 4kA/5A, 5kA/5A, 6kA/5A, 7kA/5A, 7.5kA/5A, 8kA/5A.</p> <p>Input Voltage: AC 50-600V.</p>
	KM9648-PF3	<p>Function: Power Factor Meter-Three phase only.</p> <p>Range: LEAD 0.5-1-0.5LAG.</p> <p>Input Current: For Current below AC 5A, the meter can be used directly. For Current above 5A, Current Transformer (C.T.) must be used. Press Key \curvearrowright to select desirable C. T. Ratio. The following are the available C.T. Ratios: 10A/5A, 15A/5A, 20A/5A, 25A/5A, 30A/5A, 40A/5A, 50A/5A, 60A/5A, 70A/5A, 75A/5A, 80A/5A, 100A/5A, 120A/5A, 150A/5A, 160A/5A, 200A/5A, 250A/5A, 300A/5A, 400A/5A, 500A/5A, 600A/5A, 700A/5A, 750A/5A, 800A/5A, 1kA/5A, 1.2kA/5A, 1.5kA/5A, 1.6kA/5A, 2kA/5A, 2.5kA/5A, 3kA/5A, 4kA/5A, 5kA/5A, 6kA/5A, 7kA/5A, 7.5kA/5A, 8kA/5A.</p> <p>Input Voltage: AC 50-600V.</p>
STANDARD FEATURES		
DIMENSION		